

First Time Use

OFF/ON

Turn unit on

Slide the OFF/ON switch to the right. Switch will return to center. Display will show READY prompt.

SHIFT

PSW

12 CHARS

ENTR

Y

Set/change password

When you first receive your QuoTrek it may display the message "QA TEST 1" or "ENTER PSW". You must enter a password to make the unit operational.

Press SHIFT.

Press PSW.

Key in your 12 digit password

Press ENTR.

Press YES to confirm.

SHIFT

CH

3

ENTR

Set/change FM channel

Tune receiver to proper FM channel. Example: San Francisco = 3.

Press SHIFT.

Press CH.

Key in appropriate channel.

Press ENTR.

MODE

ADJ OK

Tune in FM station to ensure that you are receiving "LIVE" data

Press MODE to move to FM mode.

Extend antenna until OK flag is on steady and ADJ flag is off or flashing.

Select services

Press D.SEL to view system message: current date & time.
Press SCROLL to view page 1 of list of available services. Asterisk (*) denotes which services are being broadcast live.

Press SCROLL again to view second page of services.

Press CLR to return to READY prompt.

D.SEL

SCR

SCR

CLR

Tuning Tip:
OK indicates you are receiving the FM signal. ADJ indicates interference in the signal. When ADJ flag is off or flashing, data will update.

QuoTrek™
BY DATASPEED

Ready Reference Guide

Flags

✓ FILES

MSG

MODEM

FM**))

FULL

GRACE

BATT

OK

ADJ

FM receiver OFF. Stored data can be accessed.

Message(s) in memory you have not seen. Press MSG key.

Modem attached, ready for phone line communication.

FM receiver ON. "Live" data can be received.

All 40 registers in memory are full.

In 15 day grace period. Need to renew subscription.

Battery low. Plug in charger.

FM signal is received if OK indicator is steady ON.

ADJ indicator should be OFF or flashing.

Keys

OFF/ON

MODE

D.SEL

ENTR

STOR

MSG

SCR

CLR

DEL

SP

CH

PSW

SHIFT

SHIFT + SP

Slide switch to left or right. Switch will return to center.

Press to change mode.

Displays system message. Press SCR key for next page.

Key in symbol, press ENTR. Status displayed (does not store).

Key in symbol, press STOR. Displays and Stores.

Press to look at message in memory.

Press SCROLL to view next display. If pressed first, shows symbols.

Clears screen. Start over. Returns to READY prompt.

Information no longer needed in memory.

Leaves a space on screen.

Press SHIFT and then CH to change FM channel.

Press SHIFT and then PSW to update password.

Press first to use functions on "front" of keys.

= Backspace.

I	B	M
ENTR		
CLR		

Display trading symbol and last transaction (not stored)

Key in trading symbol.

Press ENTR.

Press CLR to return to READY prompt.

I	B	M
STOR		
CLR		

Display & store trading symbol and last transaction

Key in trading symbol.

Press STOR.

Press CLR to return to READY prompt.

SCR		
SCR		
CLR		

Review trading symbols in memory

Press SCRoll to view list of names of first four trading symbols in memory.

Continue to press SCRoll to view up to 10 pages of symbol names in memory.

Press CLR to return to READY prompt.

ENTR		
SCR		
SCR		
CLR		

Review portfolio

Press ENTR to view first trading symbol and latest transaction in memory.

Press SCRoll to view next trading symbol and transaction in memory.

Continue to press SCRoll to view up to 40 trading symbols and information in memory.

Press CLR to return to READY prompt.

DEL		
ENTR		
Y		

Delete transactions, not symbols

To start with "fresh" information you may wish to delete previous transactions but leave trading symbols in memory.

Press DEL.

Press ENTR.

Press "Y" to confirm.

I	B	M
DEL		
Y		

Delete individual trading symbol from memory

Key in trading symbol.

Press DEL.

Press "Y" to confirm.

DEL		
STOR		
Y		

Delete portfolio from memory

Press DEL.

Press STOR.

Press "Y" to confirm.

MSG		
SCR		
SCR		
CLR		

Review messages

Press MSG to view message.

Press SCRoll to view next message in memory.

Continue to press SCRoll to view up to maximum of 10 messages.

Press CLR to return to READY prompt.

MSG		
DEL		
Y		
DEL		
Y		

Delete individual messages

Press MSG to view message.

Press DEL to delete that message.

Press "Y" to confirm (next message in memory will appear).

Press DEL to delete next message.

Press "Y" to confirm.
Continue to delete up to maximum of 10 messages.

DEL		
MSG		
Y		

Delete all messages

Press DEL.

Press MSG.

Press "Y" to confirm.

For customer service call 800 762 7538